





TO ROTATE IN ELEVATION: FIRST, MAKE SURE LEVERS ARE IN THE UP POSITION (SHOW IN MIDDLE PICTURE ABOVE), LOOSEN HANDKNOBS (SHOWN IN RIGHT PICTURE), MAKE SURE TO HOLD ONTO THE RF HOUSING PRIOR TO LOOSEING THE LEVERS (SHOWN IN LEFT PICTURE). ONCE LOOSENED THE RF HOUSING CAN BE MOVED TO THE CORRECT ELEVATION ANGLE USING THE VERNIER ON THE SIDE (SHOWN BELOW). ONCE THE RIGHT ELEVATION IS ACHIEVED TURN LEVER (FROM MIDDLE PICTURE) TOWARDS THE CENTER OF THE PEDESTAL. THEN TURN HANDKNOBS (FROM RIGHT PICTURE) TO A POSITION THAT DOESN'T ALLOW THE ANTENNA TO MOVE.



